

CETIBOX H3 BASE LEVEL SDK



CETIBOX H3

Δ

B

1

CETITJO

CETIBOX H3

AUTOMOTIVE CONNECTED SYSTEM DEVELOPMENT

CETIBox is a comprehensive tool for Automotive Connected Systems Development, offering connectivity to all automotive field bus and networking systems in one device, be it LIN, CAN, CAN-FD, FlexRay, MOST® or Ethernet AVB. Advanced A/V features make CETIBox an ideal platform for emulation, stimulation, monitoring and script-based controlling of any IEEE 1722-2011 or 1733 (RTP) based system. Universal Gateway (UGW) and EveryIP Service Oriented Middleware, allow for RPC communications, easily configurable, time-aligned activities on all field buses, mathematical functions for routing rules and Information regrouping on different domains.

State of the art processing performance

Thanks to the RH850/F1K D8 (available option) and the R-CAR H3, the CETIBox offers all required performance for your application development with room to grow.

ORDERING OPTIONS

CETIBOX BASE LEVEL

Base Level is available to all CETiBox customers and extends the Renesas R-CAR Starter Kit BSP. Develop prototypes and evaluate features in a robust and resilient hardware platform, with state of the art in vehicle network interfaces.

CETIBOX SDK

Enabling the quick and efficient implementation of distributed applications and services. CETiBox SDK includes the necessary middleware and driver components to speed up your application development.

Complete access to services and signals inside the device and over the network(s), with toolchain supported development workflow.

CETiBox SDK is available with CETITEC Software components preintegrated to suit your application case:

- Universal Gateway
- EveryIP Service oriented middleware with code generation straight from interface definition.
- Network Drivers for automotive networks (e.g CAN-FD,

USE CASES

CETiBox allows you to:

- Connect newly developed devices to an existing car platform for initial in-car tests
- Easily migrate your products into new bus technologies by connecting your 1st devices to an existing car platform
- Develop your own application code with middleware and networking drivers support*
- Easily exchange signals between field bus messages and your own applications*

PART LIST

- CETiBox H3 compact hardware
- Quick start guide
- Online user manual
- Composer (additional license required)
- Integra (additional license required)
- Automotive Connectors

PRODUCT HIGHLIGHTS

- IEEE 1722-2011
- IEEE 1733 (RTP)
- Audio-Listeners and Talkers
- Video-Listeners and Talkers
- IEEE 802.1AS (gPTP), Grand-Master, Slave and Bridge
- 100Base-T1 (BroadRReach) and Standard 1000BASE-T Eth. Support
- 6 Port AVB Switch with up to 5 100 Base-T1 interfaces
- Scripting support (Automation) HTTP interface
- Automotive Networks: CAN, CAN-FD, Ethernet, MOST

NEXT STEPS

Request for Quotation: sales@cetitec.com Further Information: +49 (7231) 95688-62 INTERFACE

Cyclic Time DefaultValues Length Type Messare Group R

CAN ID

CAN ID For

t

nayView ¥ X	Operations View	Message Pool View	Gateway View					* X
omposer \ Gateway \ CAN1 \ 3nput Messages \ 0x • Track Active Bern		A. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.						
Find Previous Find Next Sort Messages - Operation Preview				• Find	Cear			
+ #1 0x79, 'CAN, 79, DR" -	Drag a column header here to group by that column							
 In Oct 20, "CAN Message BCDstaff" 	Triggering Message	Triggering T	Input		Operation	Output	Send Attr	Direct R
#20 0x230, "CAN_Message Buffered False" #20 0x230, "CAN_Message Buffered True" #20 0x230, "CAN_Message Calculate_Signal" *********************************	CANI, Du 10, "CAN, Hessage Takula & CANI, Du 10, "CAN, Hessage Takula & CANI, Du 10, "CAN, Hessage Takula & Canitate Signal CANI, Du 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & Canitate Signal CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL DU 10, "CAN, Hessage Takula & CANITA & CANITAL				CAN2.0x180, "CAN_Message C CAN2.0x180, "CAN_Message C	DIRECT		
	CANLORED, CAN, Message Calcula 0x180, "CAN, Message Calcula - Galoaste Signa CANLORED, "CAN, Message Calcula - Galoaste Signa CANLORED, "CAN, Message Calcula - Galoaste Signa			- f- Calculate Signal	CAN2.0x180, "CAN_Message C CAN2.0x180, "CAN_Message C	DIRECT		
	Ox180, "CAN_Message V	ia Input messa	CANLOX180, "CAN_Message Calcula CANLOX180, "CAN_Message Calcula CANLOX180, "CAN_Message Calcula CANLOX180, "CAN_Message Calcula			CAN2.0x181, "CAN_Message C CAN2.0x182, "CAN_Message C CAN2.0x181, "CAN_Message C CAN2.0x181, "CAN_Message C	ORECT	
(bx 100, 'CAN_Message' Calculate_Signal".Byte 2 * 0x10, 'CAN_Message' Calculate_Signal".Byte 2 * 0x10, Calculate Signal I DRECT if (bx 100, 'CAN_Message 'Calculate_Signal".Byte 2 								
0x130, "CAN_Message "Calculate_Signal".8yte 6 = 0x250, "CAN_Message "Calculate_Signal".8yte 7	3							
Catchere Signer 104/201	Error List Outp	. The second sec						+ X
etis Yev • X	🔕 0 Errors 🔥 21 Wa	emings 📣 0 Messay	pes III					
n, on jesse cause jena	Description		a controllare		Source			Categ *
91								

COMPOSER – CONVERSION RULE CONFIGURATION TOOL

0xf

0+18

Stan

With the CETITEC Composer application (PC) you can configure all aspects of the Automotive Bus Converter to convert data between the most important automotive bus-systems such as CAN, Ethernet, MOST, FlexRay* and LIN* as well as the signal interchange with PC-applications*.

CETITEC COMPOSER USER INTERFACE

Editing or Importing of Message Catalogues and Routing Configuration Data

Composer is used to create definitions of messages and signals on different buses manually or to simply import existing message catalogues from standard formats. Based on the message and signal information the routing configuration (gateway table) could be easily defined. The Composer can also be extended* with import filters for OEM or customer specific data formats (messages and signals) as well as translation rules.

DYNAMIC SIGNAL EXCHANGE BETWEEN NETWORKS*

The Universal Gateway (UGW) option on the CETi-Box supports an easy transformation of information (based on telegram or signal level) between different automotive bus systems in terms of:

TFB 0x220

ETITE

- bus systems on different speeds or different physical layers
- different transport protocols*
- adaptation of bus specific features like notification mechanisms
- different message timing on source and target bus
- different transmission timing for outgoing messages (e.g. cyclically or follow-up style)
- modification of transmission types (e.g. fro cyclic transmission to an event driven 'send-on-change' manner or vice versa)
- 1:n or n:1 message to signal translations
- powerful signal and message management for initial, void and default values*

* OEM specific customization, adaption or add-on modules required

2

itegi itegi